

DIGITAL OUTDOOR LIGHT SENSOR

***Ideal for Security Lighting,
Holiday Lighting,
Landscaping and
Recreational
Areas.***

TO OPERATE:

Plug the timer into a 3-conductor outlet.

Using the selector button:

SELECT	DESCRIPTION
F	No Power.
O	For constant power on.
1 to 9	On at dusk. Set off time for 1-9 hours.*
d	On at dusk, Off at dawn.
1. to 9.	On immediately. Set off time for 1-9 hours.*

*Cycle repeats every 24 hours.

AUTOMATIC TIMING

Lights turn on automatically at dusk and off at dawn.

MANUAL TIMING

Set the timer for lights to turn on and off. For **Security**: while you're away from home. For **Holiday Lighting**: plug your outdoor Christmas lights into your timer.

CAUTION! Total cumulative wattage of all lights must not exceed 1000 watts. Use three conductor outlet only. Do not immerse in water.

 **INTERMATIC INCORPORATED**

<http://www.intermatic.com>
©Copyright 1998 Intermatic Inc.