

DT101, DT111 SETUP

HOW TO SET TIMER:

1. DEPRESS AND SLIDE ORANGE "ON" TAB AROUND DIAL TO TIME (AM OR PM ON DIAL) YOU WANT LAMP OR APPLIANCE TO TURN ON.
2. REPEAT STEP 1 ABOVE, SET BLACK "OFF" TAB TO TIME YOU WANT LAMP OR APPLIANCE TO TURN OFF.
3. ROTATE DIAL CLOCKWISE AND LINE UP TIME OF DAY ON DIAL (THE TIME WHEN YOU DO THIS SETTING) TO THE "TIME OF DAY" ARROW ON CASE.
4. PLUG LAMP OR APPLIANCE CORD INTO TIMER AND PLUG TIMER INTO WALL OUTLET.

HOW TO OPERATE TIMER:

- TURN LAMP OR APPLIANCE ON AND CHECK THAT KNOB ON SIDE OF TIMER IS PUSHED IN.
Timer will follow the program set in steps 1 to 4 above and will repeat it every 24 hours until you pull the side knob OUT to establish manual control.
- WITH KNOB OUT YOU CAN TURN YOUR LAMP OR APPLIANCE ON OR OFF PERMANENTLY, AT ANY TIME, BY TURNING THE KNOB ON SIDE IN EITHER DIRECTION.
- TO RETURN TO AUTOMATIC CONTROL, PUSH THE KNOB ON SIDE IN. WITH KNOB IN, YOU CAN STILL TURN YOUR LAMP OR APPLIANCE ON OR OFF MANUALLY, WITHOUT EFFECTING FURTHER AUTOMATIC CYCLES.



MODEL D-101



INTERMATIC