






**MODEL: E911      24 - HOUR AUTOMATIC TIMER**  
**FOR AUTOMATIC PROGRAMMING (REPEATS EVERY 24 HOURS).**




1. DEPRESS TAB – MOVE TO **TURN ON** TIME,
2. DEPRESS TAB – MOVE TO **TURN OFF** TIME.
3. TURN DIAL CLOCKWISE  ONE COMPLETE REVOLUTION SO CORRECT TIME-OF-DAY IS OPPOSITE TIME-OF-DAY INDICATOR.
4. TURN APPLIANCE ON, PLUG INTO TIMER, AND PLUG TIMER CORD INTO OUTLET. 

- TO TURN THE APPLIANCE ON OR OFF MANUALLY AT ANY TIME, PUSH MANUAL CONTROL IN. THIS WILL **NOT** AFFECT THE NEXT AUTOMATIC OPERATION.
- TO STOP AUTOMATIC OPERATION (BUT KEEP TIMER RUNNING), **PULL OUTWARD** ON KNOB. 
- TO RESUME AUTOMATIC OPERATION, **PUSH INWARD** ON KNOB UNTIL IT CLICKS. 
- IN CASE OF POWER FAILURE, RESET TIMER. SEE (3) ABOVE.

*FOR EXTENSION AND REPLACEMENT CORD, USE 16 AWG. ALL NEOPRENE TYPE HEATER CORD.*

**CAUTION: DO NOT USE WITH SUNLAMP. WATTAGE OF LAMPS OR APPLIANCES BEING CONTROLLED SHOULD NOT EXCEED CAPACITY OF TIMER.**

15 AMPS. - 1875 WATTS - 1/3 HP.,  
 1500 W. TUNGSTEN - 125 V. A.C. - 60 HZ.



**INTERMATIC INCORPORATED,**

SPRING GROVE, IL. 60081  
 MADE AND PRINTED IN U.S.A.