

## **HB88RC EASY-SET INSTRUCTIONS**

Clear timer memory by removing the battery from the rear battery compartment for 1 minute, reinstall the battery and the display will show MO, OFF & 12:00AM.

**Plug timer into an outlet and enter the programming times first then the clock times**

### **TO PROGRAM:**

1. Press PROGRAM button once. The display will show all 7 days of the week & 1ON --:--.
2. If you want the same time ON all 7 days, press the HOUR & MIN buttons for your desired ON time.

NOTE: If you desire individual day programming, press the DAY button for your desired day(s).

3. Press PROGRAM button once. The display will show all 7 days of the week & 1OFF--:--.
4. If you want the same time OFF all 7 days, press the HOUR & MIN buttons for your desired OFF time.

NOTE: If you desire individual day programming, press the DAY button for your desired day(s).

5. Repeat steps 1-4 for any additional ON/OFF programming.

### **TO SET CLOCK:**

1. Press CLOCK button once.
2. Press MODE button to display AUTO mode.
3. Press and hold the CLOCK button down.
4. Press DAY button for the current day of week.
5. Press the HOUR & MIN buttons for the current time of day.
6. Release the clock button.

That concludes programming the timer. Make sure whatever device you are plugging into the timer is turned to the ON position. Plug this device into the bottom of the timer and plug the timer into a known good GFCI protected outlet.

**\*\*\*To delete an accidental setting or remove an unwanted time, Go to that event, hold down the mode button and press the Prog button to clear.**